

CARING FOR YOUR ARTEMA FIBERGLASS DOOR SYSTEM

To maintain the beauty and performance of your Artema door, a simple care routine will help protect your investment for years to come:

STEP	FREQUENCY	CLEANABILITY
1. Clean Gently	Every 2–3 months	Wipe the door with a soft cloth and mild soap-and-water. Avoid abrasives or pressure washing.
2. Inspect the Finish	Twice a year	Check for fading, dullness, or wear—especially on doors exposed to sun or weather.
3. Reapply Clear Topcoat	Every 1–2 years	Lightly sand and apply a UV-protective, exterior-grade clear coat to protect the finish.
4. Refinish When Needed	Every few years	If heavily weathered, re-stain or repaint the door and apply a protective clear coat.

Dear Homeowner,

We trust this Care & Maintenance guide brings confidence and ease to the stewardship of your exterior door. Crafted to support your discerning choices, it is only the beginning of our commitment to your home.

*For tailored guidance or expert insight, our specialists remain at your service.
customerservice@artemadoors.com*

*Warm regards,
The Artema Team*

CONTACT INFORMATION:**Headquarters/Billing****Address:**

402725 Grey County Road 4, Unit 2
Durham, ON N0G 1R0

Artema Door Gallery**Address:**

6260-13 Hwy 7, Woodbridge, ON,
L4H 4G3, Canada

